

Ultimo Custom Cabinetry Care Guide



Follow along for information regarding Preventative Care and Cleaning tips for your cabinetry!

**ULTIMO**[®]
CUSTOM CABINETRY
by TUSCAN HILLS[®]



Preventative Care

We manufacture cabinets using a **catalyzed conversion varnish finish**. We utilize the best materials and techniques available. However, even the best cabinetry finishes are not designed for repeated exposure to water.

- Always wipe up food and beverage spills **immediately** after they occur.
- Do **not** wax your cabinets or use abrasive cleaners, powder-cleaners, or furniture cleaners that remove wax build-up.
- Do **not** allow oven cleaners to touch your cabinetry.

Cleaning

We recommend the following to clean cabinetry:

- Use a damp, clean, lint-free cloth that is free of loose fibers. Microfiber cloths or towels work very well.
- **Do not** use a cloth or towel that you use on dishes or countertops. These could contain detergents, residue, and fibers that can harm your cabinets.
- If a cleaner is necessary, **use a mild, liquid, non-abrasive** cleaner such as Murphy's Oil Soap. Apply the cleaner to your cleaning cloth. **Do not** apply the cleaner directly to the cabinet.
- Work in small areas so that you can dry the cabinet **immediately** with a clean, lint-free cloth.

Please email service@tuscanhillscabinetry.com or call (888) 888-7404 if you have any questions during or after installation.



Removing Grease

It is only natural that grease can become an issue for kitchen surfaces. We recommend the following to remove any grease build-up on cabinets.

- Use a clean, lint-free cloth that is free of loose fibers.
- Mix a solution of equal parts white household vinegar and water. Dampen your cleaning cloth with this solution.
- **Do not** apply the solution directly to the cabinet.
- Work in small areas so that you can dry the cabinet immediately with a clean, lint-free cloth.

Climate Control

Note that wood cabinetry installed in certain climates will take on or lose moisture, causing swelling or shrinkage of certain components.

- Doors will swell in **humid environments**, especially slab-style doors. Cabinetry installed in humid geographical locations require an air-conditioned environment to alleviate the chance of any humidity issues.
- For **drier locations**, or in winter when humidity is low, a humidifier should be used to maintain a moderate level of moisture in the installation environment. While shrinkage may not be as significant as potential swelling, it can occur.

Touch-Up

Even with normal use, you will need to touch up your cabinetry. We recommend keeping your touch-up material, provided with your delivery, in a safe place for future needs!